

# SECUREDRIVE™

## MECHANICAL BREAKDOWN PROTECTION



Over the lifetime of your vehicle ownership, adding miles to your car also means adding the need for repair. Instead of worrying about the many things that could go wrong with your vehicle, let **SecureDrive Mechanical Breakdown Protection (MBP)** provide you comfort, by going beyond your manufacturer's warranty, in terms of coverage and time.

### THREE REASONS WHY

- 1** Enjoy the comfort of knowing you're covered for the cost of an unexpected repair after your manufacturer's warranty ends.
- 2** Adding a benefit bundle can enhance your coverage plan so you don't have to sweat the small things, like being stuck on the side of the road.
- 3** We're there to provide you with quality coverage and repairs, no matter the age, make or model of your vehicle.

**Comfort of coverage.**

[securedrive.ca](https://securedrive.ca)

Flexible coverage options available for all purchase types: new and pre-owned vehicles, including electric/hybrid.

### ELITE PLAN

Supreme protection to ease your worry. All vehicle components are covered except for a select list of exclusions.

### ESSENTIAL PLAN

Extensive coverage across the powertrain and many critical components that can be costly to repair.

### BASIC PLAN

Coverage for the critical parts that run your vehicle.

#### INCLUDED IN YOUR PLAN



#### 24 Hour Roadside Assistance

Nobody wants to sit on the side of the road waiting for their vehicle to repair itself. Take comfort in knowing we're there when you need us.



#### Trip Interruption

Enjoy the comfort of lodging and a meal up to \$150 per day, \$750 per event when you experience a breakdown and a repair lasts overnight.




#### Rental Benefit

Don't lose time on the road while your vehicle is being repaired. We'll cover a rental vehicle for up to \$65 per day, \$260 per repair visit.



#### Light Commercial Use (e.g. Ridesharing)<sup>3</sup>

Using your vehicle to make money on the side, with Uber for example, should never be stressful. We'll still cover your vehicle, so all you need to worry about is your driver rating.



This graph is for illustrative purposes only and may not accurately represent your manufacturer's warranty.

## Wondering about typical repair costs?

In the event something does go wrong, a repair may cost more than you think.<sup>1</sup>

Engine replacement	\$12,000
Differential repair	\$3,000
Alternator replacement	\$1,200
Air conditioning repair	\$2,000
Fuel pump replacement	\$1,200
Rear park assist camera	\$490
Transmission replacement	\$6,000
Leaking cylinder head gasket	\$1,600
Four wheel drive, transfer case repair	\$2,000
Master brake cylinder replacement	\$800
Electric / Hybrid power converter / inverter	\$3,200
Airbag assembly replacement	\$2,500

Contact your dealer for more information or call 1-866-287-6200.

# Want more comfort from your protection plan?

Add this **benefit bundle** to your plan, use with no deductible.



## Keyless Remote Mobile Protection

If you lose or damage your phone and you use your mobile phone to open your vehicle (OEM enabled door lock) we will cover up to one repair or replacement.



## Multi-media Software Package

We'll cover the cost up to \$500 in manufacturer recommended software updates to your vehicle's onboard infotainment systems, so you don't end up in the ocean when you were trying to get to the grocery store.



## Claim-Free Reward\*

If you never file a claim against your protection plan, you can still get value by selecting one of the following three options:

1. A refund cheque of the amount paid for your MBP (inclusive of taxes) up to \$1000; or
2. A store credit at your selling dealer for the full amount paid for your MBP (inclusive of taxes) up to \$2000; or
3. A SecureDrive credit for the total amount paid for your MBP protection plan, for use at your selling dealer, towards the purchase of a new MBP protection plan or other SecureDrive product.

## OPTIONAL PLAN UPGRADES

---



### Genuine OEM Parts

When your vehicle needs a replacement part, you're covered for genuine parts from the original manufacturer.



### Tire Storage<sup>2</sup>

Instead of using your winter tires as a nightstand, we cover up to \$150 per calendar year for storage.

Contact your dealer for more information or call 1-866-287-6200.

[securedrive.ca](https://www.securedrive.ca)

- \* The claim-free reward benefit is not available on the Basic plan.
1. These values are for illustrative purposes only and may not represent your repair cost.
  2. The tire storage benefit is only available at participating dealers.
  3. Refer to your Mechanical Breakdown Protection contract/policy for a full list of exclusions and limitations.

This brochure only provides you with a summary of the Mechanical Breakdown Protection product. Please refer to the MBP contract/policy for complete details of eligibility, coverage and exclusions that apply when you purchase this product and that supersede the contents provided in this brochure. The Mechanical Breakdown Protection contract/policy may not be available in all provinces or territories and specific provisions may vary based upon individual provincial or territorial requirements. Where applicable this product is underwritten by Trisura Guarantee Insurance Company, 333 Bay Street, Suite 1610, Toronto, ON; Telephone (416) 214-2555; Fax (416) 214-9597; [www.trisura.com](http://www.trisura.com).

LGM Financial Services Inc., "LGM", "SecureDrive" and applicable logos are trademarks of LGM Financial Service Inc. All Rights Reserved.

## Covered Components<sup>3</sup>

	Elite	Essential	Basic Plan
<b>Engine</b> (plus all internally lubricated parts)			
Cylinder block, cylinder head(s)	●	●	●
Diesel engine injector pump and injectors	●	●	●
Water pump	●	●	●
Oil pump and oil pump housing	●	●	●
Harmonic balancer	●	●	●
Timing chain cover	●	●	●
Intake and exhaust manifolds	●	●	●
Valve covers	●	●	●
Engine mounts	●	●	●
Seals and gaskets	●	●	●
<b>Turbocharger / Supercharger</b> (plus all internally lubricated parts)			
Turbocharger / supercharger housing	●	●	●
Seals and gaskets	●	●	●
<b>Transmission</b> (automatic or standard, plus all internally lubricated parts)			
Transmission case	●	●	●
Torque converter	●	●	●
Flywheel / flex plate	●	●	●
Vacuum modulator	●	●	●
Electronic shift control unit	●	●	●
Transmission cooler and lines	●	●	●
Transmission mounts	●	●	●
Oil pan	●	●	●
Seals and gaskets	●	●	●
<b>Transfer Case</b> (plus all internally lubricated parts)			
Transfer case	●	●	●
Seals and gaskets	●	●	●
<b>Drive Axle</b> (plus all internally lubricated parts)			
Drive axle cases	●	●	●
Locking hubs	●	●	●
Drive shafts and yokes	●	●	●
Universal joints	●	●	●
Centre support bearing	●	●	●

	Elite	Essential	Basic Plan
Constant velocity joints	●	●	●
Wheel bearings / hub assemblies	●	●	●
Axle bearings	●	●	●
Four-wheel drive actuator	●	●	●
Differential cover	●	●	●
Axle shaft	●	●	●
Seals and gaskets	●	●	●

## Electric / Hybrid Vehicle Components

Your engine might be different but you're still covered if you experience a breakdown.

	Elite	Essential	Basic Plan
Electric motor	●	●	●
Manufacturer-supplied high voltage cables	●	●	●
Power converter / inverter	●	●	●
Home charging unit	●	●	●
Hybrid / Electric vehicle battery	●	●	●
Hybrid / Electric battery charger	●	●	●
Generators	●	●	●

	Elite	Essential	Basic Plan
<b>Steering</b>			
Steering box or rack and pinion gear (plus all internal parts)	●	●	●
Power steering pump and hoses	●	●	●
Steering knuckles	●	●	●
Pitman arm	●	●	●
Idler arm	●	●	●
Tie rod ends and drag link	●	●	●
Upper and lower steering column shafts & couplings	●	●	●
Internal tilt-wheel mechanism	●	●	●
Power cylinder and pump	●	●	●
Electronic control unit / solenoid	●	●	●
Phase control unit	●	●	●
Stepper motor	●	●	●

	Elite	Essential	Basic Plan
Control valve	●	●	●
Seals and gaskets	●	●	●
<b>Electrical</b>			
Alternator	●	●	●
Voltage regulator	●	●	●
Starter motor, starter solenoid and starter drive	●	●	●
Engine compartment wiring harness(es)	●	●	●
Electronic ignition module	●	●	●
Crank angle sensor	●	●	●
Knock sensor	●	●	●
Ignition switch and ignition switch lock cylinder	●	●	●
Front windshield wiper motor	●	●	●
Rear window wiper motor	●	●	●
Washer pump and switch	●	●	●
Stop lamp, headlamp and turn signal switches	●	●	●
Multi-function switch	●	●	●
Heater / A.C. blower speed switch	●	●	●
Manual heater / A.C. control assembly	●	●	●
Horns	●	●	●
<b>Air Conditioner</b>			
Condenser	●	●	●
Compressor	●	●	●
Clutch and pulley	●	●	●
Air conditioning lines and hoses	●	●	●
Evaporator	●	●	●
Idler pulley and idler pulley bearing	●	●	●
High / low compressor cut-off switch	●	●	●
Expansion valve	●	●	●
Pressure cycling switch	●	●	●
Seals and gaskets	●	●	●
<i>The following parts are also covered if they are required in connection with the repair of a covered air conditioner part listed above:</i>			
Accumulator / receiver dryer	●	●	●
Orifice tube	●	●	●

	Elite	Essential	Basic Plan
Oil and refrigerant	●	●	
<b>Enhanced Electrical</b>			
Automatic climate control programmer	●	●	
Electronic instrument cluster	●	●	
Gauges	●	●	
Mileage computer	●	●	
Distributor	●	●	
Ignition coil	●	●	
Electronic combination entry system	●	●	
Cruise control module and transducer	●	●	
Cruise control servo and amplifier	●	●	
Cruise control engagement switch	●	●	
Headlamp motors	●	●	
Power window motor and switches	●	●	
Power seat motor and switches	●	●	
Power mirror motor and switches	●	●	
Power antenna motor	●	●	
Mast assembly	●	●	
Convertible top motor	●	●	
Power sunroof motor	●	●	
Powertrain control module	●	●	
Rear defogger switch	●	●	
Power door lock actuators and switches	●	●	
Global positioning system (GPS)	●	●	
Navigation system	●	●	
CD / DVD player and radio	●	●	
Rear-distance monitoring system	●	●	
MFG satellite support system (example: OnStar™)	●	●	
<b>Brakes</b>			
Master cylinder and power brake cylinder	●	●	
Vacuum assist booster	●	●	
Hydro boost	●	●	

	Elite	Essential	Basic Plan
Disc brake caliper	●	●	
Wheel cylinders	●	●	
Compensating valve	●	●	
Brake hydraulic lines and fittings	●	●	
Hydraulic control unit	●	●	
Parking brake assembly and linkages	●	●	
Electronic control processor	●	●	
Wheel speed sensors	●	●	
Pressure modulator valve / isolation dump valve	●	●	
Accumulator	●	●	
Hydraulic pump / motor assembly	●	●	
Seals and gaskets	●	●	
<b>Fuel Delivery</b>			
Fuel pump	●	●	
Fuel distributor and injectors	●	●	
Sensors (except oxygen sensor)	●	●	
Vacuum pump	●	●	
Fuel tank sending unit	●	●	
Metal fuel delivery lines	●	●	
Idle Air Control (IAC) motor	●	●	
Seals and gaskets	●	●	
<b>Front and Rear Suspension</b>			
Upper and lower control arms	●	●	
Control arm shafts and bearings or bushings	●	●	
Upper and lower ball joints	●	●	
Radius arm and bushings	●	●	
Torsion bars and mounts or bushings	●	●	
Stabilizer bar, links and bushings	●	●	
Spindle and spindle support	●	●	
Variable dampening suspension system	●	●	
<b>Cooling</b>			
Engine cooling fan, motor and relay	●	●	
Fan clutch	●	●	

	Elite	Essential	Basic Plan
Belt tensioner	●	●	
Radiator	●	●	
Heater core	●	●	
Thermostat	●	●	
Blower motor	●	●	
Hot water valve	●	●	
<b>Emissions</b>			
Vapour canister	●		
PCV valve hose	●		
EGR adapter plate	●		
Air bypass valve	●		
A.I.R. manifold and A.I.R. check valve	●		
Diverter valve	●		
Canister purge solenoid	●		

	Elite	Essential	Basic Plan
 Light Commercial Use <sup>3</sup>	✓	✓	✓

**ELITE PLAN COVERAGE** ✓

**All Vehicle Components<sup>3</sup>**

Examples of additional covered components are:

- Airbags
- Heated seat elements
- Lane assist system
- Fuse box
- Wiring
- Power window regulator
- Coil springs (suspension)
- Windshield washer reservoir and spray nozzles
- Rear park assist cameras and system

**EXCLUSIONS APPLY**

Mechanical breakdowns already covered by your manufacturer's warranty and those that are caused by lack of maintenance as outlined in your manufacturer's warranty, are not covered by MBP protection plans.

**NON-COVERED COMPONENTS<sup>3</sup>**

Accessory items such as electronic keyless entry transmitter (key fob) and non-factory audio equipment. Maintenance related items such as batteries and exhaust systems. Cosmetic items such as glass, lenses and sealed beams.